

**YAMAHA G22 Brush Guard
Installation Instructions
Black- Part# 6274
Gunmetal- Part# 7071
Stainless- Part# 6274-S**



Parts List

- Brush Guard-1
- 3/8 x 3 Bolts-2
- 3/8 Flatwashers-2
- 3/8 Locknuts-2



 *Always wear appropriate eye protection!*

1. Remove the front bumper from the cart as shown in Figure 1, save the two bolts for future installing the brush guard.
2. Loosely install the brush guard to the stock bumper bolt location using the stock bolts as shown in Figure 2.
3. Using the supplied bolts, washers, & locknuts bolt the brush guard to the stock frame holes as shown in Figure 2.
4. Securely tighten all bolts.



Figure 1



FIGURE 2



866-405-2537

www.jakesliftkits.com