

**Universal Grab Handles
Installation Instructions
Black- Part# 53206 Stainless-Part# 53201**



Parts List
Grab Handles-2
Hdw Kit-1



 **Always remember to wear appropriate eye protection!**

1. Hold one of the grab handles up to the roof strut in the desired location. With a colored marker mark the drilling holes on the roof strut as shown in FIGURE 1.
2. Using a center punch indent the marks you made in the roof struts to prepare for drilling as shown in FIGURE 2.
3. Using a 5/16" drill bit drill completely through the roof struts.
4. Using the supplied hardware bolt the grab handle to the inside of the roof strut as shown in FIGURE 3.
5. Repeat the same steps for the other side of the cart. **NOTE: Before marking drill holes for the other side measure up the roof strut to determine where to mount the so it is level with the completed side.**



866-405-2537
www.jakesliftkits.com