

**E-Z-GO Header/Performance Kit
Fits Lifted E-Z-GO's w/ 295CC
Motors w/ Cast Iron Manifolds
Installation Instructions
Header Only Part# 7050
Header & Performance Kit Part# 7055
Performance Kit Only Part# 7055-B**



Header Instructions Part# 7050:

1. Take off old muffler.
2. Remove cast iron manifold.
3. Using stock manifold gasket, bolt Zemco header to cart with supplied bolts.

Performance Kit Instructions Part# 7055-B:

1. Remove stock air-box / air-cleaner system.
2. Save all gaskets for re-use. If any gaskets are torn they will need to be replaced or a thin layer of RV silicone must be used.
3. Attach Jake's custom velocity stack to carburetor using the stock nuts from the air-box.
4. Put plastic male coupler on crankcase ventilation which was attached to the air-box.
5. Prepare air-cleaners as service kit instructs.
6. Install small air filter to the crankcase ventilation port and the larger air filter to the velocity stack.
7. After installation is finished, run your cart. If you need to choke the cart more than usual stop. Provided is a #63 (.063) drill bit. Using this bit enlarge the stock jet as shown in picture.
8. If the cart still needs choked to stay running you will need to purchase a larger drill bit and enlarge the jet. Different altitudes and temperatures will require different jetting.



866-405-2537

www.jakesliftkits.com