

JAKES LIFT KITS

EZ-GO ST/Clays Car Models Factory Lifted w/ Old Style Steering

PART # 7254

PARTS LIST



FRONT INSTALLATION

1. Lift the cart with a jack and place on jack stands. Remove the wheels and tires.
2. Unbolt the front leaf springs from the axle. Unbolt the front shocks.
3. Using the supplied nuts/bolts **ITEM C** bolt, leaf spring risers **ITEM A**, & stainless steel front shield **ITEM D**, and stock 3 holed spring plates bolt the risers, leaf springs, and spring plates to the front axle. The front shield is pre-drilled and will mount on the bottom of the front using the 2 front riser bolts as shown.
4. Install new shock extensions **ITEM E** to either the top or bottom of the shock.
5. Replace the right hand threaded tie rod end from both the driver & passenger tie rod, with the new right hand thread heim **ITEM F**. Install the supplied spacer on top of each spindle and reattach to each tie rod as with supplied allen head bolt & lock nut **ITEM F** as shown in Figure 2.

Figure 2



REAR INSTALLATION

1. Lift the rear of the cart and place it on jack stands. Place a jack under the rear axle housing.
2. Replace rear leaf spring shackles with new shackles provided **ITEM B**.
3. Securely tighten all bolts.

