

Yamaha G29 JW1 Gas Skid Plate

Part# 7249

Parts List

Skid Plate-1

5/16 x 3/4 bolts-2

5/16 locknuts-2



Installation Instructions:

1. Jack the rear of the car up and place it on jack stands.
2. There are 2 stock 3/16" holes in the stock bottom swing arm. Using a 5/16 drill bit enlarge these holes from the bottom as shown in FIGURE 1.
3. Using the supplied 5/16 x 3/4 bolts and locknuts mount the front of the skid plate to the enlarged holes as shown in FIGURE 2.
4. Hold the rear of the skid plate up to the rear. Remove the bolt that the rear mount lines up with. Bolt the rear mount to the rear using the stock bolt as shown in FIGURES 2 & 3.
5. Securely tighten all bolts.

