

Club Car Precedent Sport Windshield Part# 7480

Parts List

Windshield Assembly-1
Hardware Kit-1



Installation Instructions:

1. Remove the stock rubber grommets and roof struts from both sides of the car as shown in Figure 1. Save the rubber grommets for reinstallation.
2. Place the rubber grommets on each side of the sport windshield mounts. **NOTE: Some grommets may need trimmed or cut for proper fitment.**
3. Place the windshield assembly in place to the stock roof strut location. With the supplied spacer on the outside of the windshield mount bolt the windshield to both sides of the car using the supplied 8MM x 1.25 x 80 bolts as shown in Figure 2. **NOTE: The spacer has two holes for mounting. The hole closest to the end of the spacer goes down as shown in FIGURE 2. The windshield is designed to lean back towards the steering wheel.**
4. Slide the stock rubber grommets back into place. Using the supplied self tapping screws bolt the rubber grommet into place as shown in Figure 3. If your stock grommet is not cut out for the roof struts you will need to make a small cut on the top side of the grommet to slide windshield mount through.

